



INSTALLATION STEPS:

- 1: APPLY A CONTINUOUS BEAD OF CCW BARRIBOND OR LM-800XL DETAIL SEALANT AT VapAir SEAL 725TR OR MD STEP OFF. BEAD SHALL BE TOOLED TO A MINIMUM OF 1" (25mm) WIDE BY 40 MILS THICK AND ALLOWED TO DRY ACCORDING TO INSTALLATION INSTRUCTIONS.
- 2: APPLY CCW BARRITECH, BARRISEAL OR BARRITHANE ON THE WALL, CONTINUING IT 2" (51mm) ONTO THE PREVIOUSLY INSTALLED VapAir SEAL PRODUCT.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 4](#).

	<p>0</p> <p>REFER TO NOTES</p>	<p>ROOF BARRIERS:</p>	<p>WALL BARRIERS:</p>	<p>1.11</p>
		<p>VapAir SEAL 725TR OR MD</p>	<p>BARRITECH, BARRISEAL OR BARRITHANE</p>	
<p>REFER TO SPECS FOR ADDITIONAL INFORMATION</p>				