



INSTALLATION STEPS:

- 1: INSTALL A MINIMUM 6" (153mm) WIDE STRIP OF CCW 705FR-A OVER PRIMED SUBSTRATE, CENTERED DIRECTLY BELOW THE PLANNED TIE-IN LOCATION. REMOVE RELEASE LINER AND PRESS INTO PLACE. ROLL TRANSITION STRIP WITH 2" HAND ROLLER.
- 2: INSTALL CCW 705VP ON THE WALL, EXTENDING IT 3" (76mm) ONTO PRIMED 705FR-A TRANSITION MEMBRANE. REMOVE RELEASE LINER AND PRESS INTO PLACE. ROLL ENTIRE OVERLAP WITH 2" HAND ROLLER.
- 3: INSTALL VapAir SEAL 725TR OR MD OVER PRIMED CCW 705FR-A TRANSITION MEMBRANE. REMOVE RELEASE LINER AND PRESS INTO PLACE. ROLL ENTIRE OVERLAP WITH 2" HAND ROLLER TO ENSURE FULL ADHESION.

NOTES:

- 1 IF TIE-IN OCCURS ON A VERTICAL SURFACE, APPLY A CONTINUOUS BEAD OF DOW 758 SILICONE WEATHER BARRIER SEALANT AT BUTT JOINT TO PREVENT THE BUCKING OF WATER. BEAD SHOULD BE TOOLED TO A MINIMUM OF 1" (25mm) WIDE BY 40 MILS THICK.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 4](#).

	<p>0</p> <p>REFER TO NOTES</p>	<p>ROOF BARRIERS:</p> <p>VapAir SEAL 725TR OR MD</p>	<p>WALL BARRIERS:</p> <p>705VP</p>	<p>1.9</p>
		<p>REFER TO SPECS FOR ADDITIONAL INFORMATION</p>		