


INSTALLATION STEPS:

1. INSTALL CCW 705 AIR BARRIER PRODUCT (ALL OPTIONS OF CCW 705 ARE ACCEPTABLE) ON WALL, EXTENDING IT A MINIMUM OF 6" (153mm) ONTO PRIMED MIRADRI 860/861 TO CREATE A SHINGLED JOINT. REMOVE RELEASE LINER AND PRESS INTO PLACE USING HAND PRESSURE.
2. ROLL ENTIRE OVERLAP USING A 2" HAND ROLLER TO REMOVE AIR POCKETS AND TO ENSURE FULL ADHESION.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 5.](#)

	<div style="border: 1px solid black; width: 20px; height: 20px; display: flex; align-items: center; justify-content: center; margin: 0 auto;">0</div> <p>REFER TO NOTES</p>	<p>WALL BARRIERS:</p> <p>705, 705FR-A OR 705VP</p>	<p>BELOW GRADE BARRIERS:</p> <p>MIRADRI 860/861</p>	2.1
	REFER TO SPECS FOR ADDITIONAL INFORMATION			