


INSTALLATION STEPS:

1. INSTALL CCW 705 AIR BARRIER PRODUCT (ALL OPTIONS OF CCW 705 ARE ACCEPTABLE) ON WALL, EXTENDING IT A MINIMUM OF 6" (153mm) ONTO PRIMED BARRICOAT TO CREATE A SHINGLED JOINT. REMOVE RELEASE LINER AND PRESS INTO PLACE USING HAND PRESSURE.
2. ROLL ENTIRE OVERLAP USING A 2" HAND ROLLER TO REMOVE AIR POCKETS AND TO ENSURE FULL ADHESION.

NOTES:

- 1 IF USING 705VP ON THE WALL, BARRICOAT NEEDS TO BE FULLY CURED PRIOR TO INSTALLATION. BARRICOAT CAN NOT TOUCH THE FABRIC (FACE) SIDE OF THE 705VP.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 5.](#)

	0 REFER TO NOTES	WALL BARRIERS: 705, 705FR-A OR 705VP	BELOW GRADE BARRIERS: BARRICOAT	2.2
	REFER TO SPECS FOR ADDITIONAL INFORMATION			