


INSTALLATION STEPS:

1. APPLY 30 MILS OF CCW 703V LIQUISEAL OVER PREVIOUSLY INSTALLED CCW MIRASEAL WATERPROOFING SYSTEM. 703V LIQUISEAL MUST BE APPLIED A MINIMUM OF 6" (153mm) OVER THE MIRASEAL AND CONTINUED ONTO THE SUBSTRATE A MINIMUM OF 1" (26mm).
2. INSTALL CCW 705 AIR BARRIER PRODUCT (ALL OPTIONS ARE ACCEPTABLE) ON WALL, EXTENDING IT A MINIMUM OF 6" (153mm) ONTO THE PREVIOUSLY INSTALLED AND CURED CCW 703V LIQUISEAL. REMOVE RELEASE LINER AND PRESS INTO PLACE USING HAND PRESSURE. ROLL OVERLAP USING A 2" HAND ROLLER.
3. AT 705/703V LIQUISEAL STEP-OFF, APPLY A CONTINUOUS BEAD OF SEALANT (SEE CHART ABOVE FOR SEALANT OPTIONS) TOOLED TO A MINIMUM OF 1" (26mm) WIDE BY 40 MILS THICK. ALLOW TO DRY ACCORDING TO SPECIFIC PRODUCT INSTALLATION INSTRUCTIONS

NOTES:

1 DETAIL REQUIRES THE USE OF TRANSITION MATERIAL CONSISTING OF CCW 703V LIQUISEAL. 705 PRODUCTS ARE NOT PERMITTED FOR DIRECT CONTACT WITH CCW MIRASEAL.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 5.](#)

	<p>0</p> <p>REFER TO NOTES</p>	<p>WALL BARRIERS:</p> <p>705, 705FR-A OR 705VP</p>	<p>BELOW GRADE BARRIERS:</p> <p>MIRASEAL</p>	<p>2.3</p>
		<p>REFER TO SPECS FOR ADDITIONAL INFORMATION</p>		