

INSTALLATION STEPS:

1. APPLY A CONTINUOUS BEAD OF CCW BARRIBOND OR LM-800XL DETAIL SEALANT AT MIRADRI 860/861 STEP OFF WHERE BARRITECH OR BARRISEAL WILL BE APPLIED. BEAD SHALL BE CONTINUOUS, AND TOOLED TO A MINIMUM OF 1" (25mm) WIDE BY 40 MILS THICK AND ALLOWED TO DRY ACCORDING TO INSTALLATION INSTRUCTIONS.
2. APPLY BARRITECH, BARRISEAL OR BARRITHANE ON THE WALL, CONTINUING IT A MINIMUM OF 6" (153mm) ONTO THE MIRADRI 860/861.

BARRIBOND LIQUID FLASHING & DETAIL SEALANT OR LM-800XL, 1" (25mm) WIDE TOOLED RIBBON @ 40 MILS THICK.

- WALL AIR BARRIER OPTIONS
- BARRITECH NP
 - BARRITECH VP
 - BARRISEAL
 - BARRITHANE


6" (153mm) min.

- CCW CONTACT ADHESIVE OPTIONS
- 702
 - 702 WB
 - 702 LV
 - 715
 - CAV-GRIP
 - AWP

- BELOW GRADE WATERPROOFING OPTIONS
- MIRADRI 860/861

APPROVED SUBSTRATE

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 5.](#)

	<p>0</p> <p>REFER TO NOTES</p>	<p>WALL BARRIERS:</p> <p>BARRITECH, BARRISEAL OR BARRITHANE</p>	<p>BELOW GRADE BARRIERS:</p> <p>MIRADRI 860/861</p>	<p>2.4</p>
		<p>REFER TO SPECS FOR ADDITIONAL INFORMATION</p>		