


INSTALLATION STEPS:

1. APPLY CCW BARRITECH, BARRISEAL OR BARRITHANE AIR BARRIER PRODUCT ON WALL AND CONTINUE IT A MINIMUM OF 6" (153mm) OVER PREVIOUSLY INSTALLED CCW BARRICOAT.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 5.](#)

	<div style="border: 1px solid red; padding: 2px; display: inline-block;">0</div> REFER TO NOTES	WALL BARRIERS: BARRITECH, BARRISEAL OR BARRITHANE	BELOW GRADE BARRIERS: BARRICOAT	2.5
		REFER TO SPECS FOR ADDITIONAL INFORMATION		