


INSTALLATION STEPS:

1. APPLY 30 MILS OF CCW 703V LIQUISEAL OVER PREVIOUSLY INSTALLED CCW MIRASEAL WATERPROOFING SYSTEM. 703V LIQUISEAL MUST BE APPLIED A MINIMUM OF 6" (153mm) OVER THE MIRASEAL AND CONTINUED ONTO THE SUBSTRATE A MINIMUM OF 1" (26mm).
2. APPLY CCW BARRITECH, BARRISEAL OR BARRITHANE ON THE WALL, EXTENDING IT A MINIMUM OF 6" (153mm) ONTO THE PREVIOUSLY INSTALLED AND CURED CCW 703V LIQUISEAL.

NOTES:

- 1** DETAIL REQUIRES THE USE OF TRANSITION MATERIAL CONSISTING OF CCW 703V LIQUISEAL. 705 PRODUCTS ARE NOT PERMITTED FOR DIRECT CONTACT WITH CCW MIRASEAL.

THIS DETAIL DEPICTS PRODUCTS COMPATIBILITY ONLY. FOR COMPLETE ROOF-TO-WALL TIE-IN, PLEASE SEE [SECTION 5.](#)

	<p>0</p> <p>REFER TO NOTES</p>	<p>WALL BARRIERS:</p> <p>BARRITECH, BARRISEAL OR BARRITHANE</p>	<p>BELOW GRADE BARRIERS:</p> <p>MIRASEAL</p>	<p>2.6</p>
		<p>REFER TO SPECS FOR ADDITIONAL INFORMATION</p>		