



NOTES:

- 1 USE STRIP OF CCW 705FR-A TO BRIDGE BETWEEN INSULATIVE SHEATHING BOARD AND BELOW GRADE WATERPROOFING
- 2 FILL GAPS AT R2+SHEATHE BOARD JOINTS OR PENETRATIONS, EXCEEDING 1/8" (3mm) WIDTH, WITH LOW RISE BEAD OF FOAM SEALANT.
- 3 SEALANT/MASTIC SHALL BE TOOLED TO 40 MILS AND COMPLETELY COVER STEP OFF, TERMINATION BAR & FASTENERS
- 4 TO CREATE A WATER AND AIR TIGHT SEAL, TREAT BOARD JOINTS WITH CCW OR HUNTER FOIL-GRIP 1402 FLASHING TAPE REFERRING TO CCW DETAIL SH-2A.3

	0	WALL BARRIERS:	BELOW GRADE BARRIERS:	5.9
	REFER TO NOTES	Xci CLASS A OR R2+ SHEATHE	MIRASEAL	
REFER TO SPECS FOR ADDITIONAL INFORMATION				