
INSTALLATION STEPS:

- 1: APPLY APPROPRIATE CCW PRIMER A MINIMUM OF 3" (76mm) ONTO THE FACE OF THE PREVIOUSLY INSTALLED CCW-705 AND A MINIMUM OF 3" (76mm) ONTO SUBSTRATE
- 2: INSTALL A MINIMUM 6" (153mm) WIDE STRIP OF CCW 705FR-A CENTERED OVER STEP-OFF OF PREVIOUSLY INSTALLED AIR BARRIER SO THAT 3" (76mm) EXTENDS ONTO THE PRIMED CCW-705 AND THE REMAINING 3" (76mm) EXTENDS BEYOND STEP-OFF, ONTO PRIMED SUBSTRATE. INSTALL BY REMOVING THE RELEASE LINER AND PRESSING INTO PLACE. ROLL CCW 705FR-A STRIP WITH 2" HAND ROLLER.
- 3: APPLY APPROPRIATE ROOF MEMBRANE BONDING ADHESIVE OVER SUBSTRATE, CONTINUING 2" (51mm) ONTO THE CCW 705FR-A. ALLOW ADHESIVE TO FLASH OFF ACCORDING TO SPECIFIC ADHESIVE INSTALLATION INSTRUCTIONS.
- 4: INSTALL PVC/KEE HP ROOF MEMBRANE, EXTENDING IT 3" (76mm) ONTO THE CCW 705FR-A. CUT ROOF MEMBRANE AS STRAIGHT AS POSSIBLE TO HELP WITH ALIGNMENT OF TERMINATION BAR. ROLL OVERLAP WITH 2" HAND ROLLER TO ENSURE FULL ADHESION, ENSURING THE LAST 1" (26mm) OF THE ROOF MEMBRANE IS NOT ADHERED TO ALLOW APPLICATION OF UNIVERSAL SINGLE-PLY SEALANT HIGHLIGHTED IN STEP 4.
- 5: APPLY A CONTINUOUS BEAD OF UNIVERSAL SINGLE-PLY SEALANT A MINIMUM OF 1/2" (13mm) IN DIAMETER BETWEEN THE FACE OF THE CCW 705FR-A AND UNDERSIDE OF THE PVC/KEE HP ROOF MEMBRANE. SEALANT SHALL BE APPLIED DIRECTLY IN LINE WITH PLANNED TERMINATION BAR LOCATION.
- 6: WHILE SEALANT IS STILL WET, INSTALL TERMINATION BAR OVER SINGLE—PLY MEMBRANE, SANDWICHING SEALANT BETWEEN THE ROOF MEMBRANE AND THE CCW 705FR—A. TERMINATION BAR SHALL BE FASTENED WITH APPROVED FASTENERS AT A MINIMUM OF 12" (305mm) ON CENTER. FASTENERS SHALL PENETRATE THROUGH THE BEAD OF WATER CUT—OFF MASTIC TO ENSURE A WATER AND AIR TIGHT SEAL.



NOTES:

1 THIS DETAIL IS NOT APPLICABLE FOR FABRIC FACED 705VP. REFER TO NVELOP DETAIL 1.3C WHEN CCW-705VP IS USED.

